




INSTALLATION INSTRUCTIONS



2009-2015 NISSAN 370Z 3.7L

PART NO. 19135

BILL OF MATERIALS:



HARDWARE KIT:

- 1. [7] 2.50" Clamp

SHOP SUPPLIES:



WEAR SAFETY GLASSES



READ INSTRUCTIONS THOROUGHLY BEFORE INSTALLING PRODUCT



SPRAY LUBRICANT

To ease removal of existing exhaust components (especially on older vehicles) spray penetrating lubricant on all fasteners and hangers/insulators that will be loosened or removed and let soak before disassembly.

MINIMUM REQUIRED TOOLS:



13,15 mm



Hanger Tool (Or Pry Bar)

MAGNAFLOW RECOMMENDS PROFESSIONAL INSTALLATION ON ALL THEIR PRODUCTS



WARNING: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

ATTENTION: Always install any supplied band or U-bolt clamps to the proper torque specifications of 40-45 ft-lb for band clamps and 30-35 ft-lb for U-bolt clamps. Over tightening will result in the clamps breaking and will NOT be warranted by MagnaFlow.

MAGNAFLOW: 1901 Corporate Centre Dr - Oceanside, CA 92056 | 1(800)990-0905

Technical Support: 1(800) 959-9226 | Email: moreinfo@magnaflow.com


INSTALLATION INSTRUCTIONS



Step 1. Begin removal of the OEM exhaust by unbolting the inlet pipes from the catalytic converters at the flange junctions.



Step 2. Unbolt the flange coupling the inlet pipe assembly to the resonator assembly to ease the system removal process. Working front to rear disengage all welded hangers from the rubber insulators. Retain all mounting hardware as it will be needed to install your new MAGNAFLOW system.



Step 3. Loosely install the new Inlet Pipe Assembly to the X-Pipe Assembly with the supplied clamp. Next, loosely bolt both inlet flanges to the catalytic converter outlets using the OEM gaskets and fasteners.



Step 4. Next, loosely attach both Resonator Assemblies to the X-Pipe Assembly outlets using the supplied clamps. Locate both welded hangers to the rubber insulators.

INSTALLATION INSTRUCTIONS



Step 5. Install the Muffer Assembly by loosely attaching the inlets to the Resonator Assembly outlets using the supplied calmps. Locate the welded hangers to the rubber insulators.



Step 6. Install both Tail Pipe Assemblies to the Muffer Assembly. Loosely secure using the supplied clamps.



Step 7. Once a final position has been chosen for the new exhaust system, evenly tighten all clamps and fasteners from front to rear using the torque specifications on page one of these instructions. Inspect all fasteners after 25-50 miles of operation and re-tighten as necessary.