


### 2006 - 2007 Dodge Ram 1500 MC IFS 5.7L



**Warning:** When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

**Step 1:** (Carefully read all instructions before installation) Unbolt the clamp attaching the OEM inlet pipe to the catalytic converter extension pipe. Unbolt the OEM clamps fastening the muffler and tail pipe assemblies. The OEM system can now be removed by disengaging the welded hangers from the OEM rubber isolators (Do not damage the OEM rubber isolators, as they will be reused to mount the new system.)

**Step 2:** Fasten the Inlet Pipe to the catalytic converter extension pipe using the supplied 3.00" clamp assembly. Be sure to engage the location slot to the peg in the OEM pipe. Install the muffler assembly, and tip in the same fashion using the supplied 2.50" clamps. Leave all clamps and fasteners loose for final adjustment of the complete system.

**Step 3:** With all components mounted loosely, adjust the system for overall aesthetics and clearance of frame & bodywork. (MAGNAFLOW recommends at least 1/2" of clearance between the exhaust system and any body panels to prevent heat-related body damage or fire.)

**Step 4:** Once a final position has been chosen for the new system, evenly tighten all fasteners from front to rear. The supplied band clamps must be VERY tight to properly align the pipes and prevent leaks (Approximately 40ft-lbs). U-bolt clamps should be tightened to approximately 30-35ft-lbs. Inspect all fasteners after 25-50 miles of operation and retighten if necessary.

**\*\* Magnaflow Performance Exhaust recommends professional installation on all their products**